

## NOTES:

- 1. NOT FOR USE ON SLOPES GREATER THAN 2:12, OR 1:12 IN AREAS OF HIGH SNOW LOADS (GREATER THAN OR EQUAL TO 21 psf).
- 2. THE LOCATION AND NUMBER OF MOUNTS, AS WELL LENGTH OF FASTENER SHALL BE DETERMINED BY THE PROJECT DESIGN PROFESSIONAL TO RESIST THE CALCULATED PRESSURES.
- 3. THE MEMBRANE ON THE ROOFTOP EQUIPMENT MOUNT SHOULD ALWAYS BE THE SAME AS THE TYPE OF MEMBRANE USED IN THE FIELD.
- 4. USE A CONTINUOUS 2" MINIMUM HEAT WELD AT THE PERIMETER OF THE TARGET.
- 5. GAF WARRANTIES AND GUARANTEES DO NOT COVER THE PERFORMANCE OF THE MOUNTS OR PUNCTURES CAUSED BY IMPROPERLY SECURED MOUNTS. REFER TO APPLICABLE GUARANTEES AND WARRANTIES AT GAF.COM FOR COMPLETE COVERAGE, AND RESTRICTIONS.
- 6. INSPECTION IS REQUIRED BEFORE OVERBURDEN IS INSTALLED.
- 7. REFER TO THE GAF ROOFTOP EQUIPMENT MOUNT INSTALLATION INSTRUCTIONS FOR DETAILED INSTRUCTIONS AND REQUIREMENTS.

## **GAF Rooftop Equipment Mount 100 Installation**



We protect what matters most™

Legend: Heat Weld

**Product:** 

GAF Rooftop Equipment Mount 100

Installation:
All PVC Systems

Maximum Warranty: See Note #5

**Date:** 8/8/2025

Scale:

Not To Scale

**Detail No.** 075419 **155**