

NOTES:

- 1. THE LOCATION AND NUMBER OF MOUNTS AND THE NUMBER OF FASTENERS AND LENGTH PER MOUNT MUST BE DETERMINED BY A DESIGN PROFESSIONAL TO HELP ENSURE THE INSTALLED SYSTEM IS SUITABLE FOR THE CALCULATED PRESSURES.
- 2. THE MEMBRANE ON THE ROOFTOP EQUIPMENT MOUNT SHOULD ALWAYS BE THE SAME AS THE TYPE OF MEMBRANE USED IN THE FIELD.
- 3. USE A CONTINUOUS 2" MINIMUM HEAT WELD AT THE PERIMETER OF THE TARGET.
- 4. GAF WARRANTIES AND GUARANTEES DO NOT COVER THE PERFORMANCE OF THE MOUNTS OR PUNCTURES CAUSED BY IMPROPERLY SECURED MOUNTS. REFER TO APPLICABLE GUARANTEES AND WARRANTIES AT GAF.COM FOR COMPLETE COVERAGE, AND RESTRICTIONS.
- 5. INSPECTION IS REQUIRED BEFORE OVERBURDEN IS INSTALLED.
- REFER TO THE GAF ROOFTOP EQUIPMENT MOUNT INSTALLATION INSTRUCTIONS FOR DETAILED INSTRUCTIONS AND REQUIREMENTS.

GAF Rooftop Equipment Mount 240 Installation



We protect what matters most™

Legend: Heat Weld

Product:

GAF Rooftop Equipment Mount 240

Installation:All PVC Systems

Maximum Warranty: See Note #4

Date:

8/8/2025

Scale: Not To Scale

Detail No. 075419

156