



NOTE:

- 1. SET PRIMED FLANGE IN ROOF CEMENT ON MOP MB, COLD MB, SA MB, AND BUR.
- 2. SET PRIMED FLANGE IN HEAT-SOFTENED MEMBRANE ON TORCH APP OR HEAT-WELD SBS SYSTEMS.



ALTERNATE ROOF PENETRATION FLASHING DETAIL
- GALVANIZED JACK

DRAWING #
516

ISSUE / REVISION DATE
4/21/21

SCALE
N.T.S.

LEGEND

BASE / PLY SHEET(S)