

## NOTES:

- 1. INSULATION MUST BE TAPERED TO CREATE A SUMP AROUND THE DRAIN WHEN THE ROOF DECK DOES NOT SATISFY THE MINIMUM SLOPE REQUIREMENTS FOR DRAINAGE.
- 2. IF REQUIRED BY LOCAL CODE, INSTALL THE INCLUDED FLOW CONTROL WEIR IN THE THROAT OF THE DRAIN.
- 3. REFER TO THE APPLICATION TABLES IN THE CURRENT GAF MANUAL FOR MINIMUM FASTENER PENETRATION PER DECK TYPE.
- 4. REQUIREMENTS AND RECOMMENDATIONS OUTLINED IN THE APPLICABLE GAF MANUAL OR GUIDE SHALL APPLY IN ADDITION TO THE DRAWING ABOVE.

## Steely™ Drain Installation



We protect what matters most<sup>™</sup>

Legend: Sealant

**Product:**Steely Drain

Installation:
All PVC Systems

Maximum Warranty: 30 Years

**Date:** 7/14/2025

**Scale:** 6" = 1'

**Detail No.** 075419

566