



1. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).

FIELD WRAPPED  
PENETRATION FLASHING DETAIL

DRAWING #  
PV-C-04

SYSTEM  
PV

SCALE  
N.T.S.

ISSUE/ REVISION DATE  
5-3-13



PV SOLAR SERIES