



NOTE:

1. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).

EXTEND REINFORCED EVERGUARD® MEMBRANE ONTO MEMBRANE SECTION POSITIONED AT DRAIN SUMP AND CUT AS SHOWN TO LAY FLAT IN SUMP. HOT AIR WELD A MIN. OF 2" (52 mm) COMPLETELY SURROUNDING AREA.



DRAWING #
518

SCALE
N.T.S.

DRAIN- SEVERE SUMP TARGET

THIS DETAIL APPLIES TO:
Adhered Systems
Ballasted Systems
Mechanically Attached Systems
TriPosite Systems

REVISION DATE
10-3-17