



**NOTE:**

1. WHERE THE TOP SHEATHING ONLY HAS TO BE EXTENDED OUT OVER A WIDE EAVE (SEE DWG. CRNL1A1), THE TOP SHEATHING ON THE FIRST INSULATION PANEL MAY BE CUT BACK AS SHOWN ABOVE. THE EXPOSED ENDS OF THE SPACERS WILL THEN PROVIDE SUPPORT FOR THE EXTENDED SHEATHING.

|  |                                |                |                                  |                              |
|--|--------------------------------|----------------|----------------------------------|------------------------------|
|  <p>www.gaf.com<br/>1 Campus Drive,<br/>Parsippany, NJ 07054</p> | BRAND SERIES<br><b>CORNELL</b> |                | <b>SPECIAL EAVE PANEL DETAIL</b> | DETAIL NUMBER<br><b>112R</b> |
|  | REVISION DATE<br>10-1-15       | SCALE<br>N.T.S |                                  | SYSTEM<br><b>THERMACAL®1</b> |