



**NOTE:**

AT PEAK INSERT EXTRA SPACER BLOCKS IF THERE IS NOT A SPACER BLOCK WITHIN 3" OF THE CUT. CUT FOAM AT ANGLE TO FIT TIGHT TOGETHER. FILL ANY GAPS WITH URETHANE SPRAY FOAM.



www.gaf.com  
1 Campus Drive,  
Parsippany, NJ 07054

BRAND SERIES

**CORNELL**

REVISION DATE

10-1-15

SCALE

N.T.S

**RIDGE VENT DETAIL**

DETAIL NUMBER

**204R**

SYSTEM

**THERMACAL® 1**