



**NOTE:**  
 1. INSTALL SHINGLES ON TOP OF PITCH SECTION PER SHINGLE INSTRUCTION.  
 2. INSTALL LOWSLOPE MEMBRANE ON FLAT ROOF AREA PER MEMBRANE INSTRUCTIONS



BRAND SERIES  
**CORNELL**

PITCHED ROOF TO FLAT ROOF DETAIL

DETAIL NUMBER  
**208R**

REVISION DATE  
 10-1-15

SCALE  
 N.T.S

SYSTEM  
**THERMACAL® 1**