



**NOTE:**

1. FIT FOAM TIGHT @ 96" (2.44 M) EDGE.
2. SCREWS OR NAILS MUST BE 1-1/2" (38.1 mm) LONGER THAN THE OVERALL NAIL BASE WALL INSULATION PANEL THICKNESS.
3. NAIL BASE WALL PANEL SHOULD NOT BE APPLIED DIRECTLY TO STUDS. PLYWOOD, OSB OR DENS DECK BASE MUST BE APPLIED TO STUDS BEFORE APPLICATION OF NAIL BASE WALL INSULATION PANEL.
4. WHEN FASTENING INTO CONCRETE OR BLOCK WALLS, USE TAPCON SCREWS OR EQUIVALENT.

LEGEND:

○ = FASTENER POSITION



www.gaf.com  
1 Campus Drive,  
Parsippany, NJ 07054

BRAND SERIES

**CORNELL**

REVISION DATE

10-07-15

SCALE

N.T.S

**31 FASTENER PATTERN**  
(LAYOUT AND SCREW PATTERN 10" O.C)

DETAIL NUMBER

**104W**

SYSTEM

THERMACAL® WALL