



NOTE:

1. SEE EVERGUARD® SYSTEM GUIDELINES IN SPEC MANUAL TO DETERMINE PERIMETER, AND CORNER ZONES.
2. IN PERIMETER ZONES, DISTANCE BETWEEN ROWS IS $\leq 60\%$ OF FIELD SPACING OR ONE ROW OF INTERMEDIATE FASTENERS (FINGERS).
3. IN CORNER ZONES, DISTANCE BETWEEN ROWS IS $\leq 40\%$ OF FIELD SPACING OR TWO ROWS OF INTERMEDIATE FASTENERS (FINGERS).
4. INTERMEDIATE ROWS OF FASTENERS (FINGERS) MAY BE INSTALLED THROUGH THE SHEET WITH A COVER STRIP OR AN ADDITIONAL MEMBRANE PLY OVER FASTENERS, IN ACCORDANCE WITH GAF'S REQUIREMENTS.

GAF

MECHANICALLY ATTACHED ASSEMBLY WITH INTERMEDIATE FASTENER ROWS

DRAWING #
101D

THIS DETAIL APPLIES TO:
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

- HEAT-WELDED SEAMS
- FASTENERS