



NOTE:

- 1. FOR INSULATION THICKNESS GREATER THAN 8" (203 mm), A COVER BOARD IS REQUIRED ON MECHANICALLY ATTACHED SYSTEMS ONLY.
- 2. BEND EVERGUARD® COATED METAL TO FORM A SEALANT BOX AS SHOWN. STRIP-IN VERTICAL SEAM WHERE BOX IS JOINED TOGETHER.
- 3. ALLOW 2" (52 mm) CLEARANCE AROUND THE PROJECTION. IF MULTIPLE PROJECTIONS, ALLOW 1" (25.4 mm) BETWEEN PROJECTION AND BOX.
- 4. INSIDE SURFACE OF EVERGUARD® COATED METAL SEALANT BOX (BARE METAL SIDE) MUST BE CLEAN AND DRY BEFORE SEALANT IS APPLIED.
- 5. EXISTING PROJECTION MUST BE CLEANED AND FREE OF ANY INSULATING MATERIALS.
- 6. 25 YEAR GUARANTEES AND ABOVE MUST USE EXTREME ACCESSORIES.
- 7. POURABLE SEALANT IS CONSIDERED A MAINTENANCE ITEM AND IS EXCLUDED FROM GUARANTEE COVERAGE.



COATED METAL SEALANT BOX PENETRATION FLASHING

DRAWING #
509

THIS DETAIL APPLIES TO:
ALL SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

 HEAT-WELDED LAP (SEE NOTE #5)