

## Getting Started

The GAF Master Flow QuickConnect™ Ventilation Control App is available on the App Store® (Apple) or Google Play™ Store (Android). It requires Android™ 5.0 and above, iOS 13 and above.

**NOTE: The App only works on a 2.4 GHz Wi-Fi connection from a smartphone or tablet.**

1. Download the GAF Master Flow QuickConnect™ Ventilation Control App.
2. Open the GAF Master Flow QuickConnect™ Ventilation Control App on your smartphone or tablet.

**New User:** Please create an account by clicking on the "Register Now" hyperlink and follow the prompts to verify your email address.

**Note:** You must have access on your mobile device to the email address associated with your QuickConnect™ Ventilation Control App account.

**Note:** You can not use a computer to respond to any App requests.

**Existing Account:** Please enter your login info to access the App.

**Note:** You may reset your password using the "Forgot Password?" hyperlink.

## Adding a Device

1. After verifying your email address, you will be directed to the login screen. Enter the email and password associated with your account. The Master Flow QuickConnect™ Ventilation Control App will open.
2. Select the "Add Device" button located at the bottom of the Ventilation Control Center.
3. Follow the instructions in the pop-up window to connect your ventilator to the App.

**NOTE:** Write down (or copy) the One-Time Password (OTP) as you will need this in the next step.

**(Apple Users Only)** Once you select "Add Device," you will be prompted to navigate outside of the App into your device Wi-Fi settings to find and connect to the vent. Open Settings > Wi-Fi and select "GAF" as the Wi-Fi network. This will open the Wi-Fi Manager, choose Configure Wi-Fi.

**(Android Users Only)** Open Settings > Wi-Fi and select "GAF" as the Wi-Fi network. Click the Gear Wheel (Settings button), select "Manage router," then go to Configure Wi-Fi in the Wi-Fi Manager.

4. Enter the SSID, this is the name of your Wi-Fi network (it should appear in a pop-up list), enter the Password of your Wi-Fi network, as well as the OTP code from Step 2. **Select "Save."**
5. Open the App, your connected ventilation device will now be visible in the Ventilation Control Center.  
**NOTE:** You may need to refresh the App to view your connected device.
6. To view the current temperature and humidity for the device, select the device from the Device List menu.
7. Select one of the three operating modes: Automatic, Timer, or Manual. These methods of control are outlined in the Operating Modes menu. Slide or tap the "Hamburger Menu" icon to access.
8. If you have connection issues or errors while using the App you may need to reset the unit. To reset the QuickConnect™ device, go to your mobile device Settings > Wi-Fi > tap the icon next to the GAF network > select "Forget This Network." Return to step number 2 of these instructions to reconnect your Wi-Fi Attic Vent with QuickConnect™ Technology.

Questions about your product or need technical assistance with setup? Please email us at [masterflowtech@gaf.com](mailto:masterflowtech@gaf.com) or call our dedicated support team at **800-211-9612**.