

protect matters most™

Technical Advisory Bulletin

To: GAF Commercial Sales, GAF Contractors, Field Services, AIS, CARE

From: Technical Services

No: TAB-C-27

Cleaning Recommendations for EverGuard® Roofs

Why Clean Your Low-Slope Roof?

There are several reasons that routine cleaning may want to be included in normal roofing system maintenance... these include:

- Keeping the surface white so that it can provide maximum reflectivity and its associated energy conservation benefits.
- Preventing the accumulation of dirt and debris... which can act as a nutrient source for algae and other plant growth.
- Preventing the accumulation of chemical contaminants on the roof surface that may harm the membrane and reduce its performance life.
- **Preventing the accumulation of food sources** for birds and other pests.

Who Should Clean Roof Surfaces?

Because of safety concerns and potential for roof membrane damage, GAF recommends that roof cleaning only be performed by a professional roofing contractor. In all cases, appropriate fall protection should be used when working on a roof surface.

How Often Should A Low-Slope Roof Be Cleaned?

The need for roof cleaning is dependent on several factors, including...

- The severity of environmental contaminants
- The frequency of rainfall
- The propensity for dirt and dust accumulation
- The roof slope and drainage characteristics

Note: Some roof surfaces may not require routine cleaning and others may require cleaning on a frequent basis. Roofs should be cleaned to address the issues described above – e.g., returning the surface to maximum reflectivity, eliminating the accumulation of dirt and debris, etc.

What Are GAF's Recommendatio ns For Cleaning An EverGuard® Membrane?

EverGuard® TPO and PVC membranes can be cleaned as follows:

- 1. **Protect** any low curbs, base flashings, or other **points where water** could enter from the use of a pressure washer.
- 2. Protect plants, shrubbery, and exterior facades, from run-off of cleaning solution.
- 3. Use a low-pressure power washer (2000 psi or lower) to clean and rinse off the top layer of dust and dirt.
- 4. Use a soft bristled, long handled brush or floor broom with a cleaning solution of a mild non-abrasive household detergent (such as Spic n' Span) and water to clean the

- surface of the roof membrane, taking care to not damage the top surface of the membrane.
- 5. Rinse the roof completely with the low-pressure power washer to rinse the cleaning solution off the roof.
- 6. **Inspect the membrane** and ensure that no damage has occurred; repair any incidental damage.

What **Precautions** Should Be Taken When Cleaning A Roof?

- 1. First, only trained professionals should be allowed on the roof to avoid any consequential damage to the integrity of the roofing system.
- 2. Fall safety requirements must be followed a wet, single-ply membrane is slippery. Use caution and follow all fall safety requirements.
- 3. Avoid walking on surfaces where the cleaning solution has not been rinsed away.
- 4. Where the run-off may come in contact with exterior facades, test a small area to make sure that there are no deleterious effects to the façade from the cleaning solution.
- 5. Be sure to make accommodations for the run-off cleaning solution to avoid damage to plants and contamination of groundwater. Always comply with all local, state, and federal requirements for water run-off.

Questions?

GAF Technical Services Can Assist You... with these and other questions you may have regarding your new roof installation. Technical Support Services can be contacted at 800-766-3411. The GAF website is a great resource for just about any question you may have or for additional information you may require. Please visit www.gaf.com to find the latest information on our products and their installation.

Important: This document supersedes any prior GAF Technical Advisory Bulletins on this topic. Please always check www.gaf.com to make sure you have the most up to date information.

1 Campus Drive, Parsippany, NJ 07054 973.628.3000 Toll Free 877.423.7663 gaf.com