


# Cleaning the GAF Quick Spray Hose & Gun



Always wear proper PPE when operating the GAF Quick Spray system.



1 Close adhesive canister valve and release pressure in hose by squeezing the trigger. Spray remaining adhesive in hose into a trash bag until all pressure has been alleviated/ adhesive discarded.



2 Detach hose and gun from adhesive canister using an adjustable wrench, and attach to TPO Quick Spray Adhesive Gun & Hose Cleaner canister.



3 Fully open valve on cleaner canister and squeeze the trigger to spray cleaner through the hose and gun into a trash bag (or acceptable container), until the cleaner runs clear (time may vary depending upon the length of the hose).



4 If there is excessive adhesive buildup on the spray tip, soak a rag in the cleaner, and wipe the tip while spraying until clean.



5 Close valve on cleaner canister and release pressure in hose by squeezing trigger and spraying into a trash bag.



6 Do NOT disconnect hose unless valve is completely closed. When ready, remove hose and store.



7 For additional cleaning of the spray tip, if needed, remove it from the extension assembly using a wrench. Hold the flat spots on the extension to keep it from moving. With a second wrench, loosen the retaining cap at the end, carefully remove the spray tip, and soak it in a container with cleaner. Reinstall tip when clean.



8 Dispose of used adhesive and cleaner in accordance with applicable regulations.



Visit [gaf.com](https://www.gaf.com)

We protect what matters most™

