

# **Drill-Tec™ RhinoBond® Sell Sheet**

(COMDT225)

Updated: 5/16



*Quality You Can Trust...From  
North America's Largest Roofing Manufacturer!™*



# Drill-Tec™ RhinoBond® Attachment System

“Your Fast-And-Easy Option For Fastening Single-Ply Membranes”


**Increased Productivity...** installs in half the time as traditional adhesives. Faster dry-in.

**Saves on Materials...** no half sheets needed, fewer fasteners

**Helps Reduce Risk...** non-penetrating fastening system which can help reduce installation errors

**Consistent Installation...** machine beeps, alerting the user the sheet is welded

**Excellent Wind Uplift Performance...** spreads the wind load evenly across the roof



The RhinoBond® welded membrane spreads the wind load evenly across the roof (left, above) as opposed to the traditional in-seam fastening method (right, above), leading to less flutter – especially with wide sheets.

INDUCTION-WELDED Membrane Application

**The Drill-Tec™ RhinoBond® Attachment System** allows roofers to achieve the look and performance of a fully adhered roof at nearly the cost of a mechanically attached system. This system is designed for use over many

insulation systems: EnergyGuard™ Polyiso, EnergyGuard™ HD/HD Plus Polyiso, DensDeck® Prime, SECUROCK®, high-density wood fiber board, and plywood.




- A. RhinoBond® Induction Welding System**  
Non-penetrating fastening system for TPO and PVC single-ply roofing.
- B. RhinoTrac® Automated Installation Tool**  
For use with Drill-Tec™ RhinoBond® TPO & PVC XHD® Plates

Quality You Can Trust... From North America's Largest Roofing Manufacturer!™



# Drill-Tec™ RhinoBond® Attachment System




## Single-Ply Membrane Application ▶

- A.** EverGuard® TPO, EverGuard Extreme® TPO, or EverGuard® PVC Reinforced Membrane
- B.** GAF Drill-Tec™ RhinoBond® Plates and Fasteners
- C.** Insulation or cover board
- D.** Approved roof deck

## Professional's Best Choice

- **No Fastener Penetrations...** in field or seams of the membrane
- **No Adhesives...** no waiting for cure, no fumes, no mess, no empty pails
- **No VOCs...** safer for the environment, non-polluting LEED® credit eligible
- **Less Flutter...** optimized attachment across entire sheet
- **No Flammable Storage Issues...** at shop, transport, or on roof
- **Faster Install...** quick dry-in; staged installation option
- **Fewer Hassles...** no half sheets in perimeter—and fewer seams too
- **High Wind Uplift Capability...** FM-approved system details available
- **Backed by GAF,** North America's largest roofing manufacturer

## Install Single-Ply Membranes in Four Easy Steps



Step 1

Attach insulation or cover boards to deck using Drill-Tec™ RhinoBond® Plates and Fasteners.



Step 2

Roll out EverGuard® TPO 45, 60, or 80 mil membrane or EverGuard Extreme® TPO 50, 60, 70, or 80 mil membrane.



Step 3

Place RhinoBond® tool over coated plate... and push the button. Wait about 5 seconds for the beep.



Step 4

Clamp with special magnetic clamp...repeat.

