



NOTE:

1. SEE EVERGUARD® SYSTEM GUIDELINES IN SPEC MANUAL TO DETERMINE PERIMETER, AND CORNER ZONES.
2. IN PERIMETER ZONES, DISTANCE BETWEEN ROWS IS $\leq 60\%$ OF FIELD SPACING OR ONE ROW OF INTERMEDIATE FASTENERS (FINGERS).
3. IN CORNER ZONES, DISTANCE BETWEEN ROWS IS $\leq 40\%$ OF FIELD SPACING OR TWO ROWS OF INTERMEDIATE FASTENERS (FINGERS).
4. INTERMEDIATE ROWS OF FASTENERS (FINGERS) MAY BE INSTALLED THROUGH THE SHEET, IN ACCORDANCE WITH GAF'S REQUIREMENTS.
5. THIS DETAIL IS BASED ON THE ROOF ZONE LAYOUT PRESCRIBED IN THE 2005 AND 2010 EDITIONS OF ASCE 7.

GAF

MECHANICALLY ATTACHED ASSEMBLY WITH
INTERMEDIATE INDUCTION WELDED FASTENER ROWS

DRAWING #
101E

THIS DETAIL APPLIES TO:
MECHANICALLY ATTACHED SYSTEMS

ISSUE / REVISION DATE
7/8/21

SCALE
N.T.S.

LEGEND

- HEAT-WELDED SEAMS
- FASTENERS