




## SINGLE-PLY: TPO & PVC 60-80 mil membranes



## NOTE:

- 1.USE DETAIL IN CONJUNCTION WITH THE STANDARD TERMINATION DETAIL FOR APPROVED ROOF SYSTEM.
- 2. A VAPOR RETARDER AT THE DECK LEVEL MAY BE USED IF THERE ARE CONCERNS WITH POTENTIAL MOISTURE ISSUES DUE TO CERTAIN CONSTRUCTION PROCESSES OR OTHER SOURCES DURING BUILDING USE.
- 3. REFER TO GAF SA PRIMER INSTALLATION INSTRUCTIONS FOR GENERAL GUIDELINES.
- 4. MAINTAIN SEPARATION BETWEEN VAPOR RETARDER AND MEMBRANE/ ADHESIVE TO AVOID POTENTIAL INCOMPATIBILITY ISSUES.
- 5. FOR STEEL ROOF DECKS: FILL STEEL DECK FLUTES WITH SPRAY FOAM INSULATION PRIOR TO THE INSTALLATION OF ABOVE DECK INSULATION A MINIMUM OF 12 INCHES (305 mm) FROM FACE OF WALL.
- 6. AIR SEAL WALL-TO-ROOF DECK INTERFACE.

	BASE WALL TERMINATION WITH SA VAPOR RETARDER				LEGEND	
GAF	DETAIL AT WALL				HEAT-WELDED	
	DRAWING#		THIS DETAIL APPLIES TO:	ISSUE / REVISION DATE	SCALE	EVERGUARD® WATER-BLOCK
	309		ADHERED SYSTEMS MECHANICALLY ATTACHED SYSTEMS RHINOBOND® SYSTEMS	4/6/21	N.T.S.	EVERGUARD® BONDING ADHESIVE